

## Exploded views


In order to operate, follow the order outlined here. Each assembly refers to the corresponding Disassembly/Reassembly (D/R) procedure in the maintenance instructions and the necessary repair kit.

### **i** Screws and fasteners


For **each** assembly indicated by a  $\diamond$ : order G03413 (KR screws and fasteners KS21) in addition to the repair kit(s).

For **each** assembly indicated by a  $\blacklozenge$ : order G03420 (KR gaskets KS21) in addition to the repair kit(s).


### Exploded view - Front



## Exploded view - Top and rear



## Exploded view - Sides and bottom



## Exploded view - Rigging



**Rigging elements are critical to the product safety.**

Maintenance on rigging elements must only be performed by L-Acoustics Certified Providers.

