

## Exploded views


In order to operate, follow the order outlined here. Each assembly refers to the corresponding Disassembly/Reassembly (D/R) procedure in the maintenance instructions and the necessary repair kit.

### **i** Screws, fasteners and gaskets

For **each** assembly indicated by a ♦: order G03202 (KR fasteners X series) in addition to the repair kit(s).


For **each** assembly indicated by a ♦: order G03199 (KR gaskets X series) in addition to the repair kit(s).

### Grill and loudspeaker



**i** Disassemble the grill and loudspeaker to access the following assemblies.

## Mechanical components



## Electronic components

